



Model No. EB116
24" 2-IN-1 FOLDABLE PEDESTAL FAN



| Blade Diameter | V/Hz | Current | CFM | RPM |
|-----------------------|-------------|----------------|------------|------------|
| 24" | 120V / 60Hz | 2.0 A | 7200 | 1080 |

READ AND SAVE THESE INSTRUCTIONS

To prevent serious injury or property damage, read and understand owner's manual before operating.

SAFETY INFORMATION

WARNING

1. Unplug the fan before moving it or performing maintenance.
Don't operate the fan when your hands are wet.
2. Do not disassemble, repair or rebuild the fan.
3. Unplug the fan when it is not in use.
4. Do not unplug the fan by holding the cable cord. Unplug by holding the plug.
5. Do not use the fan when there is damage to the cable cord or plug.
6. Do not use the fan with an extension cord.
7. Do not use the fan close to fires.
8. Do not insert your hand or other objects into the guard or near movable parts.
9. To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.

CAUTION

1. Do not submerge the fan in liquids.
2. This fan is not intended for use by children and people with reduced physical or sensory capabilities.

CARE AND MAINTENANCE

Always disconnect the power before servicing, cleaning or moving the fan to a new location. Do not use water for cleaning metal surfaces. In order to remove the dust from the protective screen, it is recommended to use a vacuum or clean with a soft cloth.

REPLACEMENT PARTS

- For replacement parts and technical questions, please call Customer Service at 1-800-280-3592.
- Not all product components are available for replacement. The illustrations provided are a convenient reference to the location and position of parts in the assembly sequence.
- When ordering parts, the following information will be required: item description, item model number, item serial number/item lot date code, and the replacement part reference number.
- Matrix Industrial Products® reserves the rights to make design changes and improvements to product lines and manuals without notice.

LIMITED WARRANTY - LIMITATIONS ON THE WARRANTY

This limited warranty does not cover: (a) normal wear and tear; (b) damage through abuse, neglect, misuse, or as a result of any accident or in any other manner; (c) damage from misapplication, overloading, or improper installation; (d) improper maintenance and repair; and (e) product alteration in any manner by anyone other than Us, with the sole exception of alterations made pursuant to product instructions and in a workman-like manner.


OBLIGATIONS OF PURCHASER

You must retain your proof of purchase in case of warranty claim

ASSEMBLY INSTRUCTIONS


1. Unfold the Front Foot

Cut the zip-tie and lower the front foot onto a flat, level surface. Install and tighten two of the provided threaded knobs (AA) at each side of the angle brackets on the front foot.



2. Unfold the Rear Foot

Cut the zip-tie and rotate the rear foot onto a flat, level surface. Install and tighten one of the provided threaded knobs (AA) at the side of the angle bracket on the rear foot.




4

3. Extending the Base


WARNING: THIS STEP MUST BE COMPLETED BEFORE OPERATING THE FAN IN A FLOOR OR PEDESTAL POSITION.

- Untighten the knob (1) and slide the bar as far as it will go to the indentation (2).
- Screw the knob (1) until tight to secure the base of the fan.



4. Raise the Fan Head


Untighten the triangular knob, lift up the fan head until a click or snap is heard and then stop.



5


5. Secure the Fan Head in place

Secure the fan head in place by tightening the triangular knob (3).



6. Adjust the Tilt Angle

Adjust the tilt angle by tightening the knob (4) in the upper pole.



6

OPERATING INSTRUCTIONS


1. Turning the Fan On/Off and Adjusting the Airflow Settings

- a) Plug the power cord into an outlet.
- b) Turn the switch to the desired speed.
 - 0=Off,
 - 1=Low
 - 2= Medium
 - 3= High

POWER CORD




DIAL



2. TRANSPORTING THE FAN

- a) Ensure the fan is unplugged from the power source before adjusting the height or angle.
- b) Fold the fan - floor mode.
 - Unscrew the triangle knob.
 - Pull the pump up and adjust the tilt angle until the fan head folds back.
- c) Use the wheels to move the fan.



3